







#	Description	Qty	#	Description	Qty	#	Description	Qty	#	Description	Qty
1	Gun body	1	14	Air cap retaining ring	1	27	Trigger	1	40	Needle spring	1
2	Rear spring washer	1	15	Air valve spring	1	28	Trigger pivot	1	41	Spring pad	1
3	Needle packing spring	1	16	Air valve spindle	1	29	Trigger pin	1	42	Needle /Fluid adjusting knob	1
4	Front spring washer	1	17	Rear air valve seal	1	30	Trigger gasket	1	43	Fluid inlet	1
5	Needle packing	1	18	Air valve	1	31	Washer	1	44	Filter	1
6	Packing nut	1	19	Air valve packing	1	32	Circlip 4	1	45	Paint cup	1
7	Air separator	1	20	Air valve packing nut	1	33	Pattern adjusting valve body	1	Accessories		
8	Spray head seal	1	21	Circlip 5	5	34	Pattern adjusting valve spindle	1			
9	Spray head	1	22	Air adjusting valve body	1	35	Pattern adjusting valve seal	1	46	Spanner	1
10	Fluid nozzle	1	23	Air adjusting knob	1	36	Pattern adjusting knob	1	47	Brush A	1
11	Air cap	1	24	Air adjusting knob seal	1	37	Screw	1	48	Male plug	1
12	Slip ring	1	25	1/4" Air inlet	1	38	Housing	1			
13	Lock ring	1	26	Trigger pivot washer	1	39	Fluid needle	1			




#	Description	Qty	#	Description	Qty	#	Description	Qty	#	Description	Qty
1	Gun body	1	14	Air cap retaining ring	1	27	Trigger	1	40	Needle spring	1
2	Rear spring washer	1	15	Air valve spring	1	28	Trigger pivot	1	41	Spring pad	1
3	Needle packing spring	1	16	Air valve spindle	1	29	Trigger pin	1	42	Needle /Fluid adjusting knob	1
4	Front spring washer	1	17	Rear air valve seal	1	30	Trigger gasket	1	43	Fluid inlet	1
5	Needle packing	1	18	Air valve	1	31	Washer	1	44	Filter	1
6	Packing nut	1	19	Air valve packing	1	32	Circlip 4	1	45	Paint cup	1
7	Air separator	1	20	Air valve packing nut	1	33	Pattern adjusting valve body	1	Accessories		
8	Spray head seal	1	21	Circlip 5	5	34	Pattern adjusting valve spindle	1			
9	Spray head	1	22	Air adjusting valve body	1	35	Pattern adjusting valve seal	1	46	Spanner	1
10	Fluid nozzle	1	23	Air adjusting knob	1	36	Pattern adjusting knob	1	47	Brush A	1
11	Air cap	1	24	Air adjusting knob seal	1	37	Screw	1	48	Male plug	1
12	Slip ring	1	25	1/4" Air inlet	1	38	Housing	1			
13	Lock ring	1	26	Trigger pivot washer	1	39	Fluid needle	1			



#	Description	Qty	#	Description	Qty	#	Description	Qty	#	Description	Qty
1	Gun body	1	12	Air/pattern adjusting valve housing	2	23	Air valve shaft seal	2	34	Needle packing	1
2	Air baffle	1	13	Air/pattern adjusting knob	2	24	Air valve shaft seal guide	1	35	Needle packing gasket	1
3	Fluid nozzle	1	14	1/4" air inlet	1	25	Air valve rod	1	36	Packing nut	1
4	Lock ring seal	1	15	Trigger	1	26	Air valve spring	1	37	Fluid inlet	1
5	Air cap	1	16	Trigger pivot	1	27	Needle/fluid adjusting guide	1	38	Filter	1
6	Air cap seal	1	17	Circlip 3	2	28	Washer	1	39	Paint cup	1
7	Lock ring	1	18	Air valve shaft sleeve	1	29	Fluid needle	1	Accessories		
8	Air cap retaining ring	1	19	Air valve shaft	1	30	Needle seat	1			
9	Air adjusting valve rod	1	20	Air valve front seal	1	31	Needle spring	1	40	Spanner	1
10	Circlip 5	2	21	Air valve housing	1	32	Needle/fluid adjusting knob	1	41	Brush A	1
11	Air/pattern adjusting valve seal	2	22	Air valve seal	1	33	Pattern adjusting valve rod	1	42	Plug	1



Ref.	DESCRIPTION	DESCRIZIONE	DESCRIPCIÓN
Ref. 1	Air cap	Ugello aria	Casquillo aire
Ref. 2	Fluid Nozzle	Ugello materiale	Pico fluido
Ref. 3	Nozzle holder	Portaugello	Soporte pico fluido
Ref. 5	Pattern adjustment set	Set regolazione ventaglio	Grupo regulación abanico
Ref. 6	Fluid needle adjustment knob	Dado regolazione astina	Tuerca regulación aguja
Ref. 7	Needle guide	Guida astina	Guía aguja
Ref. 8	Needle spring	Molla astina	Muelle de presión aguja
Ref. 9	Fluid needle	Astina	Aguja
Ref. 10	Needle packing nut	Ghiera premistoppa	Prensaestopas
Ref. 11	Air valve set	Valvola aria completa	Grupo válvula aire
Ref. 11-1	Air valve spring	Molla valvola aria	Muelle válvula aire
Ref. 11-2	Air valve	Valvola aria	Válvula aire
Ref. 11-3	Air valve seat	Corpo valvola aria	Cuerpo válvula aire
Ref. 12	Trigger stud	Perno grilletto	Perno gatillo
Ref. 13	Trigger	Grilletto	Gatillo
Ref. 14	Air adjustment set	Valvola portata aria	Válvula reguladora flujo aire
Ref. 15	Threaded bushing	Bussola filettata	Casquillo roscado
Ref. 16	Plug	Tappo	Tapón
Ref. 17	Air nipple	Raccordo aria	Conexión aire
Ref. 19	Pressurized cup set	Set tazza pressurizzata	Grupo taza presurizada
Ref. 19-1	Pressurized cup	Tazza pressurizzata	Taza presurizada
Ref. 19-3	Lid	Coperchio	Tapa
Ref. 19-4	Straight male adaptor	Raccordo rapido M	Conexión rápida M
Ref. 19-5	Air hose	Tubo aria	Tubo aire
Ref. 20	Pressure regulator set	Set regolatore di pressione	Grupo regulador de presión
Ref. 20-1	Orienting Ring	Corpo orientabile	Tuerca giratoria
Ref. 20-2	Banjo stem single	Vite cava singola	Tornillo Banjo
Ref. 20-3	Pressure regulator	Regolatore di pressione	Regulador de presión
Ref. C	Packing set	Set guarnizioni	Grupo juntas
Ref. D	Slide ring set	Set anello di scorrimento	Grupo anillo de desplazamiento
Ref. E	Antidrop set	Set antigoccia	Grupo antigoteo
Ref. F	Lid packing set	Set guarnizioni tazza	Grupo juntas taza



#	Description	Qty	#	Description	Qty	#	Description	Qty	#	Description	Qty
1	Gun body	1	13	1/4" air inlet	1	25	Air valve shaft seat ring	1	37	Needle packing	1
2	Air baffle	1	14	Trigger	1	26	Air valve rod	1	38	Needle packing gasket	3
3	Fluid nozzle	1	15	Trigger pivot	1	27	Air valve spring	1	39	Packing nut	1
4	Lock ring seal	1	16	Washer	2	28	Needle/fluid adjusting guide	1	40	Fluid inlet	1
5	Air cap	1	17	Screw	2	29	Washer	1	41	Paint cup	1
6	Air cap seal	1	18	Air valve shaft sleeve	1	30	Seat ring	1	Accessories		
7	Lock ring	1	19	Air valve shaft	1	31	Fluid needle	1			
8	Air adjusting valve rod	1	20	Air valve front seal	1	32	Needle seat	1			
9	Circlip 5	2	21	Air valve housing	1	33	Needle spring	1	42	Spanner	1
10	Air/pattern adjusting valve seal	2	22	Air valve seal	1	34	Needle spring washer	1	43	Brush A	1
11	Air/pattern adjusting valve housing	2	23	Air valve shaft seal	4	35	Needle adjusting knob	1	44	Plug	1
12	Air/pattern adjusting knob	2	24	Air valve shaft seal guide	1	36	Pattern adjusting valve rod	1			